



Add at the indicated locations the Pin Connector Round 1L
(This part is not available in the LEGO Digital Designer)

